



**BLUE OX**

# Qualifying a Flat Tow Vehicle

**Have you verified that your vehicle is flat towable with the manufacturer & in the owner's manual?**

**Have you verified any restrictions that must be followed with the manufacturer & in your owner's manual?**

**What rating is the motor home capable of towing?** \_\_\_\_\_

**What is the rating of the receiver hitch on the motorhome?** \_\_\_\_\_

**There are many components that must be used to flat tow a vehicle behind your motor home, here is what you will need:**

## Tow Bar

Choose a tow bar that matches vehicle weight & tab width of the baseplate.

**VEHICLE WEIGHT** \_\_\_\_\_ **TAB WIDTH** \_\_\_\_\_

**Go to the [blueox.com](http://blueox.com) Baseplate Finder**

## Baseplate

Installs on the frame of your vehicle, cutting & modifications are required.

**VEHICLE** \_\_\_\_\_  
**BASEPLATE PART #** \_\_\_\_\_

## Wiring Kit or Tow Light Kit

Tow Light Kit, EZ Light Kits, Diodes or Bulb and Socket Kit (the **blueox.com** baseplate page for your specific vehicle will specify the type of wiring kit available).

**WIRING KIT PART #** \_\_\_\_\_

## Accessory Kit

Provides essential accessories: tow bar cover, 3 lock set, 7-6 coiled cable & hitch immobilizer.

**2" OR 2/5" RECEIVER?** \_\_\_\_\_

**ACCESSORY KIT PART #** \_\_\_\_\_

## Supplemental Brake

The Patriot brake provides braking to the towed vehicle, reduces wear on the coach brakes & premature wear to the tow bar. Supplemental brakes are required in most states.

**We strongly recommend a supplemental brake to be used whenever you flat tow.**

## Adjustable Rise/Drop

To prevent premature wear and or damage the tow bar must be +/- 3" from level. The coach receiver hitch must be measured from the ground to center of receiver hitch on a level surface.

**2" OR 2/5" RECEIVER?** \_\_\_\_\_

**MEASUREMENT** \_\_\_\_\_

The baseplate page for your specific vehicle lists the tab height when installed on your vehicle in its stock suspension height.

## KarGard Protective Shield

Keeps rock chips on the paint of the towed vehicle to a minimum. Installed on the tow bar at the triple lug on both tow bar legs.